

DS KIT PLUS CANOPY SET-UP INSTRUCTIONS (10' x 10')



877.HUT.LIVE ☎ 877.488.5483

hutshop.com

STEP 1



Remove frame from box and stand upright in the center of the desired setup location.



STEP 2



With one or two people, gently pull the outer frame legs until the frame is slightly expanded.



STEP 3



Place the canopy top over the partially open frame. Align the canopy top with the four corners of the frame and attach the canopy velcro strip to each frame corner securely.



STEP 4



Lift the frame into position by expanding the truss bars until frame is fully extended. Lock each of the corner sliders into place by holding the leg of the frame with one hand and pushing the slider upward until the thumb lock clicks into place.



STEP 5



Adjust the frame legs to your desired height by lifting up each leg and slowly pulling out the inner leg into place until the thumb lock clicks. Repeat with other legs. Placing one foot on each corner of the footpad and slowly extending each leg into place can also extend the leg frames.

STEP 6



To raise the leg to the next level, press the thumb lock and slide the leg upward to the desired height.



Note: to unlock, simply press on the thumb lock.



P.O. Box 1003, Arlington, TN 38002

hutshop.com